

Hewlett Packard
Enterprise

HP Library and Tape Tools 4.20 Release Notes

Part Number: EH957-90970A
Published: December 2015
Edition: 1

© Copyright 2015 Hewlett-Packard Development Company, L.P.
Hewlett-Packard Company makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance, or use of this material.

This document contains proprietary information, which is protected by copyright. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of Hewlett-Packard. The information contained in this document is subject to change without notice.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

Links to third-party websites take you outside the HP website. HP has no control over and is not responsible for information outside HP.com.

Version:

4.20

Description

This release includes an updated version of HP Library and Tape Tools (L&TT).

LTT 4.20 is a major release that targets:

- LTO-7 drive support
- Save to Trace to Flash (STTF) configuration utility for LTO-6 drive
- Support for the Latest ESL G3,MSL6480, MSL4048, and MSL2024 firmware versions

Update recommendation

Recommended.

Supersedes

All earlier versions of L&TT.

Devices supported

- Virtual libraries and D2D backup devices—Reinstated support for D2D virtual drives for performance testing.
- Tape libraries and autoloaders.
- Tape drives—Same as L&TT 4.18.
- Other backup devices—Same as L&TT 4.18.

See the QuickSpecs available at http://www8.hp.com/h20195/v2/GetHTML.aspx?docname=c04168427 for a list of supported devices.

Operating systems

Table 1 L&TT operating system support

Operating system	OS variant	Last supported version of L&TT
Windows	Windows 2012 and 2012 R2 x64	Current
	Windows 8 and 8.1 (x86, x86_64)	Current
	Windows 7 SP1 (x86, x86_64)	Current
	Windows 2008 SP2 (x86, x86_64) Windows 2008 R2 SP1 (x86_64)	Current
HP-UX	HP-UX 11i v3 (PA-RISC,IPF)	Current
	HP-UX 11i v2 (PA-RISC,IPF)	Current
	HP-UX 11i (PA-RISC)	Current
Linux	RedHat EL 6.0 to 6.6 (x86, x86_64)	Current
	RedHat EL 7.0 (x86_64)	Current
	SuSE SLES 11 SP1, SP2, SP3 (X86, X86_64)	Current
Solaris	Oracle Solaris 10 Update 9 (x86, SPARC, AMD64)	Current
Mac	Mac 10.7 through 10.10 (x86) — Standalone drives, L&TT CSI only	Current

Languages

English

Enhancements and fixes in L&TT 4.20

Tape Drives:

Removed analysis of drive history from Drive assessment test.

Known issues and limitations in L&TT 4.20

Virtual libraries and D2D

- L&TT support for the most recent releases of D2D emulated drives is broken for all emulated LTO drive types, due to a change within the drive emulation behavior and therefore cannot be worked around with previous versions of L&TT.
- L&TT support is limited to what can be done with emulated devices. Please use the relevant Command View GUI for access to the support information for the physical device.

Tape libraries

- The MSL6480 does not currently support the Device Self-Test.
- Ethernet access specifics
    - Minimum firmware versions for LTO-5 drives: I58W, Y58W, Z58W
    - Minimum firmware versions for LTO-6 drives: J27W, J2AS, 22CW, 32AW
    - Minimum firmware versions for LTO-7 drives: FA12, FA13
    - Firmware update over Ethernet updates the firmware but the drives are not always rediscovered by the library on completion. HP recommends that you continue to use Command View TL or the MSL RMI for updating drive firmware in libraries.
    - Drive and L&TT behavior is unpredictable (and not fully tested) when the drive is being used at the same time that L&TT is talking to it. It is recommended that the library is quiescent when using L&TT over Ethernet, as is recommended for host access.
- The ESL G3 tape library does not offer diagnostic access over its host interface, which limits L&TT to standard functionality. This still allows most of the library tests to be run, but pulling tickets and updating firmware is not supported. Please use Command View TL to pull tickets and update library firmware. Access to the drives is unchanged and full functionality is available
- When using L&TT on a Linux operating system, firmware downloads to an MSL2024 Library may fail. If this happens, the firmware does get downloaded to the unit, but L&TT does not properly reflect the status of the unit when the download completes.
- In a library with mixed drive technologies, drive firmware cannot be downloaded from the library firmware download screen. Each drive must be selected individually for download. (Future enhancement)
- If a device is in a 'Not Ready' state, L&TT may not be able to perform all diagnostic functions. Most devices are only very briefly in this state, but some libraries can take a significant amount of time after power-up or after a firmware download before becoming ready. If this problem is encountered, wait until the device is in a ready state and then use L&TT. (Future enhancement)

Tape drive

- LTO-6 drive—Part number is not displayed in the support ticket.
- LTO-7 drive—
  - Full tape test in Media assessment test is unavailable.
  - STTF, firmware tape creator, data tape creator, and TapeAssure are unavailable.
  - No support for OpenVMS platform.

Operating system specific

- Windows — Device scan can fail intermittently with 'Unexpected Win32 error encountered during I/O scanning: 2' error message. Work-around is to re-scan.
- Windows 2008 — L&TT will sometimes APPCRASH on exit.
- Windows — if installing with Microsoft Installer package 4.5 uninstall the previous version manually first otherwise the installation will not complete correctly.
- HP-UX — Running the LTO Drive Assessment test on multiple drives concurrently can cause a core dump. The exact number is not known but is in the region of 8 or more.
- Linux in CLF (command line) mode – LTO Drive Assessment test output scrolls off the screen at the end of the test. Test results can still be found in the `ResultLog.ltt` files.
- Mac — Device performance tests are limited to approximately 220 MB/s. The *Get files from web* feature is not supported so L&TT cannot check for the availability of the latest firmware.
- VMware – L&TT has limited testing and support for standalone SAS drives and all libraries. There are no known issues. Install check and system performance tests are not supported.

Generic to tool

- There is some inconsistency between the reporting of data capacity and volume between tests. Some tests report data based on the power of 10, whereas others report data based on the power of 2. L&TT is transitioning to the power of 10–based reporting to match industry specifications.
- If L&TT is unable to automatically verify successful completion of a firmware update and is then re-selected from the previous scan, L&TT may exit with an exception. The cause is that the operating system has performed its own re-scan and logically moved the device after its update. If this happens, use L&TT rescan to locate the device. In these cases the firmware update was usually successful.

Prerequisites

- Windows
  - Device drivers for the connected tape devices/libraries or default device driver should be present.
- HP-UX
  - Devices do not need to be claimed by the operating system with ioscan for L&TT to access them.
  - The sctl driver must be installed for L&TT to access the device you want to test. L&TT builds its own pass-through SCSI device files using the sctl driver, so that driver must be installed; however, L&TT does not need the operating system to list any of the devices as "CLAIMED."

They may be listed that way (if the appropriate driver is installed), but they don't need to be for L&TT to fully access them.

- Devices must NOT be listed as "NO HARDWARE" in ioscan. If the device you want to test with L&TT is listed as "NO HARDWARE" in ioscan, the communication path between the host and the device is not working and must be fixed before L&TT will be able to communicate with the device.

- Linux
  - Device should be recognized by proc/SCSI subsystem.
  - Device drivers for the connected tape devices/libraries or default device driver should be present.
- Solaris
  - The device should be shown in the `cfgadm -al` and `prtconf -v` command output.
  - The device driver for connected tape drives and libraries or the default device driver should be present.

Installation instructions

Download L&TT from http://www.hp.com/support/tapetools

Windows

The Windows version of L&TT uses the InstallShield application.

Reboot requirements

- A reboot is required only if your system requires ASPI or an upgrade to the currently installed version. On systems that require ASPI, if the installer detects a previously installed version of ASPI older than v4.57, it will install a more recent version of ASPI, which will require a reboot.
- Issues may arise, however, when using the Miniport I/O mode with devices that use non-standard OS drivers, or are “claimed” by other applications or the OS. When using the Miniport I/O mode when a device is claimed, it may be necessary to shut down any running backup/storage application services to make the device accessible to L&TT. Alternatively, using the ASPI I/O mode may make the device accessible without requiring any further action.

Known issues

- When downloading the L&TT application from the Web to your local system, name the download folder to something other than `HP Library and Tape Tools` or the installation will fail if you attempt to install from that folder. The failure error will indicate that a different instance of the installer is already running.
- Also, do not rename the L&TT installation file. Renaming the file may create a conflict that prevents L&TT from installing.

To install the current Windows version of L&TT:

1. Download or copy the self-extracting executable file to a temporary location.

IMPORTANT: Do not rename this file. Renaming the file may create a conflict that prevents L&TT from installing.

2. Double-click the self-extracting executable file to launch the installer. The InstallShield Wizard screen is displayed.
3. Click **Next**. Read the program license agreement and click **Yes** if you agree to and accept the terms of the license agreement.

4. Read the `readme` file for any last-minute changes to the documentation, then click **Next**. The Select Features screen is displayed.
5. Select the desired components to install and click **Next**.
6. Select a destination location to install the program. You can accept the default location or click **Browse** to install to a different location. After choosing the destination location, click **Next**.
7. Indicate the program directory in which you want the setup program to create program icons and click **Next**. The program directory is created in the `Programs` directory of the **Start** menu.
8. On the Ready to start installation process screen, click **Next**. If you need to review or change installation settings, click **Back**.
9. When installation is complete, the InstallShield wizard displays its final screen. Select **Start HP L&TT** or **Run LTT InstallCheck** if you would like the wizard to start L&TT or the installation check. Click **Finish** to close the InstallShield wizard.

HP-UX and Linux

Uninstalling previous versions

Before installing L&TT on Linux, you must first uninstall any previous versions.

To determine if L&TT is already installed, use the following command:

```
rpm -qa | grep ltt
```

To remove a previous version of L&TT, use the following command:

```
rpm -e ltt
```

Installing the latest version

To install L&TT for HP-UX or Linux:

1. Log in as `root`.
2. Navigate to the temporary directory:

   ```
   cd /tmp
   ```

3. Download or copy the L&TT tar file, `hp_ltt<xx>.tar` (where <*xx*> is the version number) to this directory. If you are copying the file from a different location, enter the following (substitute the directory in which the file currently resides for <*directory name*>):

   ```
   cp /<directory name>/hp_ltt<xx>.tar /tmp
   ```

4. Un-tar the L&TT tar file:

   ```
   tar -xvf hp_ltt<xx>.tar
   ```

5. Run the install script in the `/tmp` directory:

   ```
   ./install_hpltt
   ```

   NOTE: For Linux, the L&TT installer verifies that the operating system you are installing on is supported. If the Linux distribution or release is unsupported, the install script displays a message indicating an installation failure and lists the supported operating systems.

6. After the software is successfully installed, enter the following commands to remove the `/tmp/ltt` directory and its contents:

   ```
   cd /tmp
   rm -rf ltt
   rm -rf install_hpltt
   ```

Solaris

To install the L&TT package:

1. Login as root.
2. Navigate to the temporary directory:

   `cd /tmp`
3. Download or copy `hp_ltt<xx>.tar` (where `<xx>` is the version number) to this directory.

   If you are copying the file from a different directory, enter the following command, substituting the directory in which the file currently resides for `<directory name>`:

   `cp /<directory name>/hp_ltt<xx>.tar /tmp`
4. Un-tar the L&TT tar file:

   `tar –xvf hp_ltt<xx>.tar`
5. Run the installation script in the `/tmp` directory:

   `./install_hpltt`
6. After the software is successfully installed, enter the following commands to remove the temporary files from the installation process:

   `cd /tmp`

   `rm –rf install_hpltt`

   `rm –rf HPLTT<xx>` (where `<xx>` is the version number)

Mac

1. Log in to the Mac GUI using root or full system privileges.
2. Download or copy the install file to a temporary location. The install file is `hpltt_<xx>_mac.dmg` (where `<xx>` is the version number).
3. Double-click the downloaded file. This action will mount the image.
4. Double-click the `hp_ltt<xx>.mpkg` icon.
5. Follow the screen instructions.
6. On completion, click the finish button.

Effective date

December 2015